



**AutumnWOOD**<sup>®</sup>  
H A N D C R A F T E D  
FURNITURE & DOORS

*A Division of Fox Manufacturing Co., Inc.*  
5105 Williams SE  
Albuquerque, NM 87105  
(505) 873-1432 fax (505) 873-1873  
www.autumnwood.com

---

## ADDING CLAVOS TO YOUR DOOR

Clavos are not shipped attached to your door(s) because you must finish the door before attaching any hardware items. **MAKE SURE THAT YOUR DOOR IS SEALED ON ALL SIX SIDES OF THE DOOR, INCLUDING THE TOP AND BOTTOM.**

In this box you may find - \_\_\_\_\_ Clavos ordered for your door

- Tools Required
- Pencil
  - Tape Measure or yardstick
  - Hand Drill with an 5/64" or 1/16" bit
  - Rubber Mallet or Hammer
  - A dish towel or an old t-shirt

### ATTACHING CLAVOS:

Ascertain where on your door that you would like the clavos, typically they are centered in the middle of the two vertical lines. Measure to the center of each area that you would like a clavo and mark with a pencil. Using the tape measure, place and mark the positions for the other clavos. Pre-drill into the door one-quarter of an inch (1/4") on each of the marked positions. Place the point of the clavo into the hole. Place a folded dish towel or other fabric item on top of the clavo so that the finish does not scratch. Carefully hammer the clavo straight into the wood until the head of the clavo is flush with the surface of the wood. Repeat process on remaining clavos.