



AutumnWOOD[®]
H A N D C R A F T E D
FURNITURE & DOORS

A Division of Fox Manufacturing Co., Inc.
5105 Williams SE
Albuquerque, NM 87105
(505) 873-1432 fax (505) 873-1873
www.autumnwood.com

ADDING GRILLES TO YOUR DOOR

Grilles are not shipped attached to your door(s) because you must finish the door before attaching any hardware items. **MAKE SURE THAT YOUR DOOR IS SEALED ON ALL SIX SIDES OF THE DOOR, INCLUDING THE TOP AND BOTTOM.**

In this box you will find - _____ Iron grill(s)

- Eight (8) 7/16" x 1" Black Bolts per grille

Tools Required

- Pencil or Marking Tool
- Hand Drill with an 1/8" bit
- Pliers or 3/8" socket and driver

Center the grille over the speakeasy door and mark the center of the holes on the grille with a nail punch or pencil. Mark all eight holes on the door, remove the grille. Pre-drill into the door one-half of an inch (1/2") on each of the eight marked holes. Replace the grille, careful to match up the holes in the grille to the new pre-drilled holes on the door. Start one of the included bolts into one of the pre-drilled holes. Using pliers or a socket driver, turn the bolt clockwise into the door. Be careful not to turn too tight, just enough to make the grille flush to the door. Repeat process on remaining bolts.